Spl.+A

		-
DART AEROSPACE LTD	Work Order: 23(2) A	
Description: Cover	Part Number: D3138-1	
Dwg: D3138 Rev. B	Qty: 14 6	
	Page 1 of	1

Step	Location	Procedure	Dir	D 4	
1	DC	Issue Traveler	Ву	Date	Qty
		1	U	05.04-27	10
2	PG	Issue P/O: UNITY	-	05.0-1	10
		Email or Ship DXF file to vendor	1	1	
		Laser Cut D3138-1 flat pattern per Dwg D3138		1	
		Possible Supplier: GFI or Industrial Laser			
		Material release note is required	11	05.05.04	110
3	RG	Receive and Inspect for transit damage	16	0505.09	10
		Enure material release note is attached	104	05/05/31	1000
4	QC6	Inspect dimensions as per Dwg D3138	CO	0000131	10
			0	But	
5	GA	Deburr	10	as occup	10
			4.2	05/06/01	10
6	GA	Bend as per Dwg D3138	Y	, , ,	
			2	05-0C.10	e* e0
7	QC5	Inspect work to Step 6	124	-, 02.10	10
3.5			18		7.6
8	FP	Chemical Conversion Coat per QSI 005 4.1	100	1506.10	10
		902. por Q01 000 4:1	EE	05/06/10	
9	FP	Powder Coat Grey Sandtex (Ref. 4.3.5.6) per QSI 005 4.3	II,	00100110	10
		4.3.5.6) per QSI 605 4.3	RM	16 2 10	/
10	QC3	Inspect Powder Coat	///	0506:10	6
		·	1	05-06-10	1
11	ST	Identify and Stock with part number and batch number using	u	070010	0
		fine point permanent ink marker as per view B-B top surface			
		Dwg D3138	a	DD-06-10 1	6
12	AC		u		0
		Cost / part: 5904	10	-1 /4/	
13	DC	Close W/O 71,195	ZI E	D 106/14	6
		Inspect Level 21	111	1	1
			441	K166,10	0

Rev	Date	Change	Povised P	
A	02.05.24	New issue	Revised By	Approved
В	04.11.29	Made by Laser Cut	NG	11
		made by Edder Out	KJ/RF	(111

RELEASED